## **S134 - High Temperature Additive**



## **Product Description**

Special clearcoat additive for hot and humid conditions

## **Suitable Substrates:**

• Hydrobase

Product Application	
	Add 5% to clearcoat before addition of hardener
IMPORTANT REMARKS	For Professional Use only Only use S134 over Hydrobase in hot and humid conditions. Do not exceed the recommended dosage.
	Wear suitable protection
Product Characteristics	
SDS:	Refer to the Safety Data Sheet

 $Disclaimer: Users\ assume\ full\ responsibility\ for\ any\ consequences\ resulting\ from\ the\ incorrect\ usage\ of\ our\ products.$ 

